



Fire Protection Nitrogen Generators Floor Mounting Bracket Instructions (NGP-MTG2) Mounting Kit



1. Determine location of Nitrogen Generator. Allow room for floor mounting brackets. Position generator 12" from wall for service access and cooling of aftercooler on some models.
2. Lift Nitrogen Generator and center vibration pads under feet (note pads are slightly smaller than mounting feet).
3. Attach floor mounting brackets (4) to Nitrogen Generator with supplied 3/8"x1" bolts. (Note rubber washer should be between bracket and generator).
4. Drill through one of the holes in each mounting brackets (1/2"). Use hole closest to generator if possible.
5. Install lag bolts or screws appropriate for flooring material.

